


Delta Regis Model #ESL500 - Parts List

Delta Regis Tools, Inc. 3315 Industrial 25th Street, Fort Pierce, FL 34946 Tel: (888) 500-2755 / (772) 465-4302 Fax: (866) 500-7270 / (772) 465-4368 www.deltaregis.com

Ref #	Part Number	Description	Qty	Ref #	Part Number	Description	Qty
1	DR96-10026	Cable Assembly	1	25	DR60-10060	Clutch Assembly	1
2	DR80-10193	Housing - Label Side	1	26	DR12-10028	C-Ring	1
3	DR80-10192	Housing	1	27	DR30-10067	Planet Gear	8
4	DR80-10141	Suspension Ring	1	28	DR30-10071	Front Planet Shaft	2
5	DR40-10116	Start Lever	1	29	DR30-10075	Gear	1
6	DR14-10043	Trigger Spring	1	30	DR60-10057	Gear Case	1
7	DR40-10065	Breaker	1	31	DR20-10034	Bearing	2
8	DR40-10067	Bridge Diode	1	32	DR60-10061	Upper Clutch	1
9	DR40-10073	Start Switch	1	33	DR13-10019	Steel Ball - 4.0mm	2
10	DR40-10117	Fwd/Rev Switch	1	34	DR31-10023	Output Shaft	1
11	DR80-10137	Fwd/Rev Switch Cover	1	35	DR13-10020	Steel Ball - 2.38mm	2
12	DR10-10032	Screw	3	36	DR11-10130	Clutch Spring Plate	1
13	DR54-10026	Motor Assembly	1	37	DR97-50001	Clutch Spring	1
14	DR40-10069	Capacitor	2	38	DR16-10020	Clutch Spring Seat	1
15	DR40-10068	Capacitor	1	39	DR12-10019	C-Ring	1
16	DR55-10007	Brush Cap	2	40	DR60-10032	Clutch Case	1
17	DR55-10013	Carbon Brush - pair	2	41	DR14-10048	Bit Spring	1
18	DR51-10035	Motor End Cover - Top	1	42	DR16-10016	Bit Sleeve	1
19	DR20-10033	Bearing	2	43	DR12-10010	C-Ring	1
20	DR52-10036	Armature	1	44	DR15-10044	Torque Adjusting Pin	4
21	DR50-10028	Motor Yoke Assembly	1	45	DR11-10131	Torque Adjusting Nut	1
22	DR51-10025	Motor End Cover - Bottom	1	46	DR12-10020	C-Ring	1
23	DR12-10021	Motor Clip	2	47	DR40-10075	Grounding Strip	1
24	DR52-10029	Fan	1	48	DR11-10112	Housing Nut	1



Delta Regis Model #ESL500LT - Parts List

Delta Regis Tools, Inc. 3315 Industrial 25th Street, Fort Pierce, FL 34946 Tel: (888) 500-2755 / (772) 465-4302 Fax: (866) 500-7270 / (772) 465-4368 www.deltaregis.com

Ref #	Part Number	Description	Qty	Ref #	Part Number	Description	Qty
1	DR96-10026	Cable Assembly	1	25	DR60-10060LT	Clutch Assembly	1
2	DR80-10193	Housing - Label Side	1	26	DR12-10028	C-Ring	1
3	DR80-10192	Housing	1	27	DR30-10067	Planet Gear	8
4	DR80-10141	Suspension Ring	1	28	DR30-10071	Front Planet Shaft	2
5	DR40-10116	Start Lever	1	29	DR30-10075	Gear	1
6	DR14-10043	Trigger Spring	1	30	DR60-10057	Gear Case	1
7	DR40-10065	Breaker	1	31	DR20-10034	Bearing	2
8	DR40-10067	Bridge Diode	1	32	DR60-10061	Upper Clutch	1
9	DR40-10073	Start Switch	1	33	DR13-10019	Steel Ball - 4.0mm	2
10	DR40-10117	Fwd/Rev Switch	1	34	DR31-10023	Output Shaft	1
11	DR80-10158	Fwd/Rev Switch Cover	1	35	DR13-10020	Steel Ball - 2.38mm	2
12	DR10-10032	Screw	3	36	DR11-10130	Clutch Spring Plate	1
13	DR54-10026	Motor Assembly	1	37	DR97-50001LT	Clutch Spring	1
14	DR40-10069	Capacitor	2	38	DR16-10020	Clutch Spring Seat	1
15	DR40-10068	Capacitor	1	39	DR12-10019	C-Ring	1
16	DR55-10007	Brush Cap	2	40	DR60-10032	Clutch Case	1
17	DR55-10013	Carbon Brush - pair	2	41	DR14-10048	Bit Spring	1
18	DR51-10035	Motor End Cover - Top	1	42	DR16-10016	Bit Sleeve	1
19	DR20-10033	Bearing	2	43	DR12-10010	C-Ring	1
20	DR52-10036	Armature	1	44	DR15-10044	Torque Adjusting Pin	4
21	DR50-10028	Motor Yoke Assembly	1	45	DR11-10131	Torque Adjusting Nut	1
22	DR51-10025	Motor End Cover - Bottom	1	46	DR12-10020	C-Ring	1
23	DR12-10021	Motor Clip	2	47	DR40-10075	Grounding Strip	1
24	DR52-10029	Fan	1	48	DR11-10112	Housing Nut	1